

goaudiozn

2 Posté le 08/06/2005 à 18:57



Newbie des prairies

I have exactly the same problem with my audity 2000. Does anyone have a solution or know which part out of order and has to be replaced?  
Thanks!

1 messages

good

3 Posté le 11/06/2005 à 20:43



Newbie des prairies

Hello,

J'ai un envoyé un mail au support technique, quelques heures après je recevais la réponse suivante :

(Mon audity refonctionne mais j'ai dû répéter une dizaine de fois l'opération avant qu'il ne réagisse.)

Merci à l'efficacité et la gentillesse de l'équipe E-mu!

-----

You could try to re-init the unit:

To Reinitialize a Proteus 2000 family module back to Factory Specs do the following:

NOTE: Reinitializing will overwrite the RAM with factory preset data. If you have any custom presets be sure to back them up!

First turn the power off. Once you have done this:

1. Hold both CURSOR KEYS (Arrow Keys) down and turn on the POWER at the same time. Hold the cursor keys until the unit boots up in the DIAGNOSTIC test menu.

2. Let go of the CURSOR KEYS. Turn the DATA WHEEL to the right until you see INITIALIZE USER DATA as the menu choice.

3. Press the HOME/ENTER button twice.

4. Upon completion of the reinitialization process you should see in the display 'Calibrate Knobs'. If you wish to calibrate knobs then press Home/Enter twice and follow the directions in the display. Otherwise turn the unit off and on again and begin using it normally.

Now all the factory preset information is restored.

-----

Good luck!

7 messages